The yarn sensor provided inside the unit will stop air supply when yarn is absent i.e. All bobbins are stripped. Operator need not wait to switch off air supply when stripping operation is over.

